

# OVERDRIVE<sup>®</sup> RUBBERIZED DRIVEWAY CRACK FILLER

## DRIVEWAY ACCESSORY

PRODUCT DATA

### DESCRIPTION

A premium rubberized driveway crack filler formulated to provide an elastic repair which expands and contracts to increase the longevity of the driveway surface.

### USES

Premium driveway crack filler. Used to repair cracks up to 1/2 inch wide. Performs in all temperatures providing a flexible and resilient seal. Protects the underlying soil and asphalt from the destructive forces of sun, wind, weather and moisture.

### APPLICATION

Prepare the surface to receive the OVERDRIVE Rubberized Driveway Crack Filler by using a stream of water or air to clean cracks of loose material, dust, dirt and vegetation. Lightly dampen but do not flood cracks with water. Assure all cracks are free of standing water. Cracks over 1/2" deep should be partially filled with sand.

After preparing surface, shake container for 1 to 2 minutes. Remove cap and cut spout to desired opening (1/4" suggested). Place spout in crack and squeeze container with slight hand pressure to regulate flow. Fill the crack with material to at or slightly below the surface. Do not fill cracks above the surface of the pavement. This will cause tracking and or smearing. For large or deep cracks, apply in two applications, filling halfway on the first application, then applying a second application. Finish by lightly sprinkling sand over the surface of each repaired (filled) crack to help prevent tracking. Allow 24 hours for repaired cracks to cure prior to sealing or opening to traffic. Clean tools with water immediately. Place cap on spout when not in use.

### TYPICAL PHYSICAL PROPERTIES\*

Weight Per Gallon, Lbs.	9.8
Cure Time (at recommended coverages)	4 - 8 hours to set, 24 - 48 hrs to full cure weather depending
Container Size	3.79 liters

\*All values stated as nominal



### NOTES AND PRECAUTIONS

Do not apply on cracks or expansion joints wider than 1/2" wide. Cracks in excess of 1/2" deep should be sealed mixing 1 part sand and 1 part OVERDRIVE Rubberized Driveway Crack Filler. Mix this mixture to a slurry and fill as directed. OVERDRIVE Rubberized Driveway Crack Filler is not intended for use as a surface coating for sealing pavement. Choose one of the OVERDRIVE Driveway Sealers for use in this type of application. Protect from freezing. DO NOT APPLY in damp weather, if rain is imminent, or if temperature is below 50° F.

Central District 220 West 4th Street, Joplin, Missouri 64801  
Northeast District 4500 Tamko Drive, Frederick, Maryland 21701  
Southeast District 2300 35th Street, Tuscaloosa, Alabama 35401  
Southwest District 7910 South Central Expressway, Dallas, Texas 75216  
Western District 5300 East 43rd Avenue, Denver, Colorado 80216

800-641-4691  
800-368-2055  
800-228-2656  
800-443-1834  
800-530-8868

[www.tamko.com](http://www.tamko.com)

For Technical Services call 1-800-641-4691

**TAMKO**<sup>®</sup>  
**ROOFING PRODUCTS**